

Features

- ✓ Highly efficient imaging spectrometer
- ✓ Fast, portable, and easy to use
- ✓ Rapidly identifies and locates weak gamma-ray sources
- ✓ Real-time spectroscopy, ID, and imaging
- ✓ Option for $\leq 0.8\%$ FWHM energy resolution at 662 keV and interaction-by-interaction resolution of $\leq 0.65\%$ FWHM
- ✓ Energy range covers isotopes of interest up to 3 MeV
- ✓ Ready to use in under 60 s
- ✓ Unsurpassed efficiency with $>77 \text{ cm}^3$ pixelated CZT
- ✓ Precision overlay of gamma-ray and optical images
- ✓ Images both point and distributed sources
- ✓ Integrated rangefinder
- ✓ Air/watertight for easy decontamination
- ✓ Wireless, Ethernet, or USB communication
- ✓ Cleanable for decontamination
- ✓ All non-volatile memory accessible and removable outside detector compartment
- ✓ Integrated tablet mount
- ✓ Options for gamma-ray imaging from 50 keV to 3 MeV
- ✓ Automatic report generation
- ✓ Annual recalibration and software updates included

The H1600 is H3D's highest efficiency, portable detector system. Detect, identify, and image even weak sources quickly and accurately with this user-friendly design.


The H1600 is ideal for applications in:

- Decommissioning
- Active interrogation
- Characterization
- Monitoring

Containing the most advanced room-temperature semiconductor technology to achieve spectroscopic performance competitive with cryogenically cooled detectors, the detector has:

- Compact and light-weight size
- Fast startup
- Excellent energy resolution
- Low power

Contact H3D to use the H1600 for your application.



Any options can be combined, except as noted.

Extra-High-Efficiency Option (H1600-15)

Increase crystal volume to >116 cm³. Also available as a higher-resolution H1600+-15 with no resolution guarantee.

High-Resolution Option (H1600+)

Improve energy resolution to ≤0.8% FWHM at 662 keV (coincident interactions combined) and ≤0.65% FWHM at 662 keV (coincident interactions separated).

Quantification Option (H1600Q)

Photopeak efficiency variation <1% across temperature range.


Low-Energy-Imaging Option (H1610)

Enable imaging from 50 keV to 250 keV by adding coded aperture.
Field of View: 86° × 86°
Angular Resolution: ~5° FWHM



H1600 Expected Base Specifications

Dimensions:	5.0 in x 8.0 in x 7.0 in (12.7 cm x 20.3 cm x 17.8 cm)
Weight:	11.7 lbs (5.3 kg)
Ingress Protection:	IP67 (excluding external media)
Tripod Mount Add-on:	1/4"-20 and 3/8"-16
Battery Life:	>6 hours at 23° C (73° F)
Power Input:	100-240V, 47-63 Hz
System Cooling:	Cleanable heat sink and removable fans
Startup & Operating Temp.:	-20° C to 50° C (-4° F to 122° F)
Startup Time:	<60 s at 23° C (73° F)
Energy Range:	50 keV to 3 MeV (spectroscopy) 250 keV to 3 MeV (Compton imaging)
Energy Resolution at 25° C (77° F):	≤1.1% FWHM at 662 keV (coincident interactions combined) ≤0.9% FWHM at 662 keV (coincident interactions separated)
Radiation Field of View:	4π (360°) omnidirectional (Compton imaging)
Angular Precision:	±1° source localization for all 4π (real time)
Angular Resolution:	~30° FWHM for all 4π (real time; >250 keV) ~20° FWHM for all 4π (post processing; >250 keV)
Sensitivity:	Detects 10-μCi ¹³⁷ Cs at 1 m (~3 μR/hr) in < 7 s (in natural background)
Crystal Volume:	>77 cm ³ CZT (CdZnTe)
Count-Rate Limit:	1 rem/hr (10 mSv/hr) bare- ¹³⁷ Cs equivalent
Rangefinder:	Integrated Class 2 laser; 635 nm; <1 mW
Optical Field of View:	>154° horizontal, >142° vertical; full color Option for 100° horizontal, 85° vertical with better optical res.
Optical Registration:	±2° to radiation image in front 90° × 90°
Isotope Library:	Select from 3573 ENDF isotopes & user defined; unlimited
Display:	8" 1280x800 HD tablet (mountable to back cover)
Tablet Communication:	Peer-to-peer WiFi or Bluetooth, or wired connection
Other Communication:	Ethernet RJ45 port; TCP/IP
Views:	Spectrum, gamma image, optical image, composite image
Data Storage:	Removable USB (64 GB) included
Warranty:	2 years (includes annual recalibration and software updates)
Includes:	Visualizer software for advanced post processing Power/accessory cables, stylus, and tablet Transport and storage case



H3D®, Inc. • 812 Avis Drive • Ann Arbor, MI 48108 • USA
Tel +1 734-661-6416 • sales@h3dgamma.com • www.h3dgamma.com

© 2024 H3D, Inc. All Rights Reserved. H1600 and related systems patent protected by:
U.S. Pat No. 7,411,197 & U.S. Pat No. 7,692,155 under license from the University of Michigan, and U.S. Pat No. 10,032,264.

Specifications, descriptions and images contained in this document were in effect at time of publication. H3D, Inc. reserves the right to change specifications or discontinue products without notice or obligation. All names, logos, and products herein are trademarks of their respective companies.